

Hulptabel t.b.v. uittrekstaat

blokken 600mm

blok beginnen
blok eindigen

balk beginnen
blok eindigen

balk beginnen
balk eindigen

aantal balken	rijen blokken	veld breedte	aantal balken	rijen blokken	veld breedte	aantal balken	rijen blokken	veld breedte
2	3	1,68	2	2	1,21	2	1	0,74
3	4	2,28	3	3	1,81	3	2	1,34
4	5	2,88	4	4	2,41	4	3	1,94
5	6	3,48	5	5	3,01	5	4	2,54
6	7	4,08	6	6	3,61	6	5	3,14
7	8	4,68	7	7	4,21	7	6	3,74
8	9	5,28	8	8	4,81	8	7	4,34
9	10	5,88	9	9	5,41	9	8	4,94
10	11	6,48	10	10	6,01	10	9	5,54
11	12	7,08	11	11	6,61	11	10	6,14
12	13	7,68	12	12	7,21	12	11	6,74
13	14	8,28	13	13	7,81	13	12	7,34
14	15	8,88	14	14	8,41	14	13	7,94
15	16	9,48	15	15	9,01	15	14	8,54
16	17	10,08	16	16	9,61	16	15	9,14
17	18	10,68	17	17	10,21	17	16	9,74
18	19	11,28	18	18	10,81	18	17	10,34
19	20	11,88	19	19	11,41	19	18	10,94
20	21	12,48	20	20	12,01	20	19	11,54
21	22	13,08	21	21	12,61	21	20	12,14
22	23	13,68	22	22	13,21	22	21	12,74
23	24	14,28	23	23	13,81	23	22	13,34
24	25	14,88	24	24	14,41	24	23	13,94
25	26	15,48	25	25	15,01	25	24	14,54
26	27	16,08	26	26	15,61	26	25	15,14
27	28	16,68	27	27	16,21	27	26	15,74
28	29	17,28	28	28	16,81	28	27	16,34
29	30	17,88	29	29	17,41	29	28	16,94
30	31	18,48	30	30	18,01	30	29	17,54
31	32	19,08	31	31	18,61	31	30	18,14
32	33	19,68	32	32	19,21	32	31	18,74
33	34	20,28	33	33	19,81	33	32	19,34
34	35	20,88	34	34	20,41	34	33	19,94
35	36	21,48	35	35	21,01	35	34	20,54
36	37	22,08	36	36	21,61	36	35	21,14
37	38	22,68	37	37	22,21	37	36	21,74
38	39	23,28	38	38	22,81	38	37	22,34
39	40	23,88	39	39	23,41	39	38	22,94
40	41	24,48	40	40	24,01	40	39	23,54